



NOTES

- A) Remotely Mounted
- B) Wire to DS64
- C) Wire to Tortoise Switch Machine Aux. Switches



